

25830 – Jericho Lane, East Halton

Surface Water Drainage Maintenance and Management Schedule:

Soakaway

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Inspect and identify areas that are not operating correctly. If required take remedial action	Monthly for the first 3 months of operation then annually
	Recover debris from catchment surface area where it may cause risk to performance	Monthly
	Remove sediment and debris from pre-tank system	Annually
Remedial Actions	Repair inlets/outlets/vents/overflows	As necessary
Monitoring	Inspect all inlets/outlets and upstream drainage system to ensure they are in good condition and operating as designed	Annually
	Survey inside of tank for sediment and build up and remove if necessary	Every 5 years

Permeable Paving

Maintenance Schedule	Required Action	Frequency
Regular Maintenance	Remove litter (including leaf litter) and debris from filter drain surface, access chambers and pre-treatment devices	Monthly
	Inspect surface, inlet and outlet pipework and control system for blockages, clogging, standing water and structural damage	Monthly
Occasional Maintenance	Remove to control tree roots where they are encroaching to sides of paving using recommended methods (NJUG, 2007 or BS 3998:2010)	As necessary
	Clear pipework of blockages	As necessary